


HOB0® RH Sensor Replacement Kit (HUM-RHPCB-3C) Manual

For use with UX100-011A loggers

- 1 Remove the cap from the logger case with a one quarter turn counter-clockwise.





- 2 Pull to remove the RH sensor from the board inside the logger. Discard the sensor.



- 3 Wearing gloves or finger cots to prevent contamination or damage, hold the replacement sensor by the sides of the board only. Do not touch the actual sensor (the small black square). Insert the connector on the sensor board into the pins on the board in the logger. Make sure the RH sensor is oriented with the flat part of the board pointed down (shown on reverse side) and gently insert the connector into the pins on the logger board.

WARNING: Wearing gloves or finger cots, touch the sides of the board only; do not touch the sensor (small black square)




23214-A MAN-HUM-RHPCB-3C

- 3 (continued)



When installed correctly, the flat part of the RH sensor board is pointed down and the black sensor is facing up



- 4 Place the cap over the RH sensor lining up the notches on the cap with the grooves on both sides of the sensor. Secure the cap with a one quarter turn clockwise until it snaps back in place.
- 5 Check logger status in HOB0ware to verify the RH reading.