



UX100-011A

HOBO ??/???? 2.5% ?????

????????????????????????????????????2.5%????

Important Information

??HOBOWare???USB????????HOBOWare Pro USB Drive????USB-A?USB-B????????????????



Compatible with
HOBOWare® ??

Supported Measurements

??, ????, ??

Features

- ?????LCD???
- ?????
- ?????????
- ?????????
- ?????????

What's in the box

- HOBO UX100-011 ??? 2.5% ?????
- Command™ ??
- ?????
- ?????

Contact Us

Sales (8am to 5pm ET, Monday through Friday)

- Email sales@onsetcomp.com
- Call 1-508-759-9500
- In U.S. toll free 1-800-564-4377
- Fax 1-508-759-9100

Onset Computer Corporation
470 MacArthur Boulevard
Bourne, MA 02532

Technical Support (8am to 5pm ET, Monday through Friday)

- Contact Product Support www.onsetcomp.com/support/contact
- Call 1-508-759-9500
- In U.S. toll free 1-877-564-4377

HOBO ??/???? 2.5% ????? (UX100-011A) Specifications

?????	
??	-20???70? (???4????158???)
???	±0.21°C ?0°?50°C??????????? (±0.38????32????122?????????????)
??	25°C??0.024°C??????????? (0.04????77?????????????)
????	???? 1 m/s (2.2 mph) ????? 4 ??
??	<0.1°C/? (??0.18???)

????????	
???	1% ? 95%?????
???	??? ±2.5%?10% ? 90% ?????? ±3.5%?? 25°C (77°F) ???????? 10% ??? 90% ????? ±5%
???	0.01%
????	? 1 m/s (2.2 mph) ????? 90% ? 10 ?
??	????? <1%

???	
????????	???-20°C ? 70°C?-4????158?????0 ? 95% ?????????? ??/???0°C ? 50°C?32°F ? 122°F???? USB ????
??????	1? ? 18??12?15?
????	?????????????????
????	?????????????????
????	????????????????????
????	???????????????
????	?????
?????	25°C (77°F) ??? ±1 ??
??	?? 3V CR2032 ???? USB ??
????	1??????????1????????15?????
??	128 KB??? 63,488 ????
????	USB 2.0 ??
????????	20 ?
?????	LCD ? 0° ? 50°C?32° ? 122°F?????????????????LCD ??????????
??	3.66×8.48×2.29?? (1.44 x 3.34 x 0.9 ??)
??	30? (1.06??)
????	IP50

